

Assembly Manual

The maximum load for this PEX-Uncoiler is 40 KGS




Pack and Unpack

A




All components
(Item # and Quantity)

B




Base (1) - Spread brackets outward

C




Base (1) - The round feet can be screwed to a board for better stability

D




Bracket (2) - Screw into the center of base (1)
Bracket (3) - Slide to center of base (1) and then lossely assemble with set screw (8)

E




Place tubing around bracket assembly

F




Bracket (3) - Adjust outward until coil is snug and then tighten set screws (8)

G




Bracket (5) - Assemble into position on ends of Brackets (1) & (3) and then tighten set screws (8)

H



Bracket (4) - Assemble into position on top of Bracket (2)
Eyelet (6) & Wing nut (7) - Assemble on the end of bracket (4) as shown

I



Feed tubing through the eyelet (6)
PEX Uncoiler is ready for use